

# Yealink SIP IP Phones Version60 Change Log

## 1 Introduction

1. Firmware Version: V60
2. Product Name: SIP-T28/T26/T22/T20/T12
3. Release Date: January 07, 2011

## 2 New Features

1. Added IPV6 support.
2. Supported Action URL/URI.
3. Added ACD function.
4. Added LLDP support.
5. Supported PushXML.
6. Enable Broadsoft ACD synchronization.
7. Supported Broadsoft Network Call Log.
8. Supported Broadsoft Network Phonebook.
9. Supported Zero-Sp-Touch.
10. Enabled HuaWei ATS Conference.
11. Added Watchdog function.
12. Enabled transfer RTP package from PC port.
13. Enabled optional of WAN and PC ports speed.
14. Supported Send Sound of headset can be adjusted.
15. Enabled user-defined of Button Sound and Send Sound.
16. Enabled Registration Random.
17. Enable calling out with no registration.
18. Supported Hebrew input method and displaying from right to left function.
19. Added Password Dial-up function.
20. Enabled whether Use Outbound Proxy in Dialog configurable.

## 3 Optimization

1. Optimization of Dial Plan rule.
2. Supported Auto Provision synchronization.
3. Dial Plan supported multiple accounts.
4. Added contact group.
5. Added LogOff to all web configuration pages.
6. Supported import and export contact of CSV and XML format.
7. Enabled the number of message in voicemail displayed.

8. Supported CODE of BLFList configuration.
9. Supported Delay Time of DialNow configuration.
10. Added POOL item in Softkey.
11. Added limit of input characters in DSSKEY-DTMF.
12. Modified the arrangement of the Softkey.
13. Added Black List in T20.
14. Supported Greek displayed
15. Supported Blind Transfer could be disabled.
16. Added Hold function with RFC2543.
17. Supported whether disposed the ring tone after Coloring Ring Back Tone is optional.
18. Enabled whether to terminate the 3-way conference when host hang up.

## 4 Bug Fixes

1. Fixed the issue that sends DTMF dial tone when pressing DSSKEY-DTMF in conference call.
2. Corrected the other party probability picked up without any sound several seconds ahead of a T22 call.
3. Fixed the issue that the receiving volume of headset was configured fail when using G.722 Codec.
4. Corrected overmuch message of BLF NOTIFY send from phone.
5. Now the phone could respond the 422 SIP message.
6. The function of hiding blacklist by user access level on LCD was valid.
7. Fixed T20 issue that unable to return Call History after added a contact from Call History.
8. Fixed the issue of FWD Code couldn't sent normally.
9. No Service could be displayed on LCD after all accounts were disabled. (T20)
10. Released limit of '\$' when registered an account.
11. Corrected the sound of the phone came out by speaker when a phone had voice mail and called out by handset.
12. Fixed issue that T28 couldn't hear some softphones' DTMF dial tone.
13. Corrected the problem of T2x may sent ARP packets with high frequency.

## 5 Instruction

1. Added IPV6 support.

**Instruction:** Internet Protocol Version 6 (IPv6) is a version of the Internet Protocol that is designed to succeed Internet Protocol version 4 (IPv4). It is a natural increment to IPv4. Now V60 support IPV6.

2. Supported Action URL/URI.


**Path:** Web Setting Page→Phone→Action URL

**Instruction:** Action URL: Record the operation of phone, send these corresponding information to server.

Active URI: Remote control phone for corresponding operation.

The operations that can be recorded include: Setup Completed, Log On, Log Off, Register Failed, Off hook, On hook...etc.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.



### 3. Added ACD function.


**Path:** Web Setting Page→Account→Advanced

Web Setting Page→Phone→Features.

**Instruction:** ACD (Automatic Call Distribution) is automatic call distribution equipment, is according specific Transfer Rules and distribution strategy to switch the access call to the right person.

You can change the setting of 'ACD Subscription' and 'ACD Auto Available' as the below screenshot. Then you can enable a DSSKEY-ACD to enable to login the ACD account.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.




### 4. Added LLDP support.

**Path:** Web Setting Page→Network→Advanced.

**Instruction:** The Link Layer Discovery Protocol (LLDP) is a vendor-neutral Layer 2 protocol that allows a network device to advertise its identity and capabilities on the local network.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.



### 5. Supported PushXML.

**Path:** Web Setting Page→Phone→Features→PushXML Server IP

**Instruction:** Users configure the server's IP address on Web page, when phone receives request, it will determine whether to display corresponding content on the phone which sent by the specified server or not.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.



### 6. Enable Broadsoft ACD synchronization.

**Instruction:** Now T2x support Broadsoft ACD, The phone supports synchronize with the state of Broadsoft ACD.

## 7. Supported Broadsoft Network Call Log.

**Path:** Web Setting Page→Contacts→Call Log

Save Call History: Web Setting Page→Phone→Feature

**Instruction:** V60 support to use Broadsoft network call log. This feature allows you to download call history from the server.

Also, you can decide whether to save call history on Yealink SIP phones.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

Call Log Item: Call Log1

DisplayName:

Server:

SaveCallHistory: Enabled

**NOTE**  
Call log  
This feature allows you to download call history from the server.

## 8. Supported Broadsoft network phonebook.

**Path:** Web Setting Page→Contacts→Broadsoft

**Instruction:** Now V60 support Broadsoft network phonebook. This feature allows you to download contact list from the server.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

Broadsoft Item: Item1

Broadsoft Displayname:

Broadsoft Server:

Broadsoft Port:

Broadsoft User:

Broadsoft Password:

**NOTE**  
Broadsoft Displayname  
This feature allows you to download contact list from the server. Input the URL, port, user, password and phonebook.

## 9. Supported Zero-Sp-Touch.

**Path:** Web Setting Page→Upgrade→Advanced

**Instruction:** Zero-Sp-Touch this function can help users to configure AUTOP and network parameters quickly. Enable this function, when the power is on or press the corresponding DSSKEY, the phone will turn to the Zero-Sp-Touch interface.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

Zero Active: Disabled

WaitTime: 5

PNP Config: Enabled

## 10. Enabled HuaWei ATS Conference.

**Path:** Web Setting Page→Account→Advance→Conference Type

**Instruction:** Turn on this function can make Multi-Party Conference come true; you can add or delete any attenders, also you can have a private chat with any member. This function needs the server's support.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

Conference Type: ATS

Conference URI: ATS

ACD Subscription Period(120~3600): 3000

## 11. Added Watchdog function.

**Path:** Web Setting Page→Phone→Preference→WatchDog

**Instruction:** When 'WatchDog' function is 'Enabled', phone will auto reboot after 10 seconds if some process of phone crash. When disable this function, the phone will not reboot.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

WatchDog: Enabled

## 12. Enabled transfer RTP package from PC port.

**Path:** Web Setting Page→Network→Advanced→Span to PC port

**Instruction:** Span to PC Port function is a function for transferring all the RTP packages out from PC port when this phone makes a phone call. So when you connect a computer to the PC port, will able to calls records when enable this function. Note: You should have software with the ability of collecting and analyzing on PC if you need the calls records function through it.

Span to PC port: Disabled

## 13. Enabled optional of WAN and PC ports speed.

**Path:** Web Setting Page→Network→Advanced.

**Instruction:** This function enables you to set the WAN/PC port connection speed.

Port Link: ?

WAN Port Link: auto negotiat

PC Port Link: auto negotiat

## 14. Supported Send Sound of headset can be adjusted.

**Path:** Web Setting Page→Phone→Feature


**Instruction:** With this function, you can adjust the volume send by headset.

Headset Send Volume (1~53): 29

15. Enabled user-defined of Button Sound and Send Sound.

**Path:** Web Setting Page→Phone→Features→Button Sound/Send Sound

**Instruction:** You can switch off keypad tone or the send sound with this two option.




|                        |         |   |
|------------------------|---------|---|
| Reserve # in User Name | Enabled | ? |
| Button Sound           | Enabled | ? |
| Send Sound             | Enabled | ? |
| Hotline Number         |         | ? |

16. Enabled Registration Random.

**Path:** Web Setting Page→network→Advanced→Registration random

**Instruction:** When the phone reboot, it will register automatically. If many phones register at the same time, this will affect the server, the users can set the register power up time so that the phone will random register automatically at the set time.

**Detail:** Please refer to User Manual of version 60 for detail. Click here to Yealink download website page.



|                     |   |         |
|---------------------|---|---------|
| Registration random | 0 | (0~60s) |
|---------------------|---|---------|

17. Enable calling out with no registration.

**Instruction:** When register a phone without a user name or password, this phone will register fail, but you can still make a phone call to other extension with this phone. It default by enable this function.

18. Supported Hebrew input method and displaying from right to left function.


**Instruction:** V60 supported Hebrew input method and support display from right to left function.

19. Added Password Dial-up function.

**Path:** Web Setting Page→phone→features

**Instruction:** When number entered is beginning with the password prefix, the following N numbers after the password prefix will be hidden as \*, N stand for the value which you enter in the PswLength field.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.



|                   |          |   |
|-------------------|----------|---|
| Logout Wizard     | Disabled | ? |
| PswPrefix         |          |   |
| PswLength         | 0        |   |
| PswDial           | Disabled | ? |
| PushXML Server ID |          |   |

20. Enabled whether Use Outbound Proxy In Dialog configuration.

**Path:** Web Setting Page→ Phone→Features

**Instruction:** This option is use for whether the communication between two calls via the server.



|                              |          |   |
|------------------------------|----------|---|
| RF 2043 Hold                 | Disabled | ? |
| Use Outbound Proxy In Dialog | Enabled  | ? |
| IsDeal180                    | Enabled  | ? |

## 21. Optimization of Dial Plan rule.

**Instruction:** V60 optimizes the rule of dial plan.

## 22. Supported Auto Provision synchronization.

**Instruction:** About the Auto Provision of V60, when the phones receive the auto provision request from server, they will remote auto reboot and auto provision.

## 23. Dial Plan supported multiple accounts.

**Path:** Web Setting Page→Phone→Dial plan

**Instruction:** Now the dial plan supports multiple accounts. Every plan can be effective for single account or multiple accounts.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

| Index | Prefix | Replace | Account | <input type="checkbox"/> |
|-------|--------|---------|---------|--------------------------|
| 1     |        |         |         | <input type="checkbox"/> |
| 2     |        |         |         | <input type="checkbox"/> |
| 3     |        |         |         | <input type="checkbox"/> |
| 4     |        |         |         | <input type="checkbox"/> |
| 5     |        |         |         | <input type="checkbox"/> |
| 6     |        |         |         | <input type="checkbox"/> |
| 7     |        |         |         | <input type="checkbox"/> |
| 8     |        |         |         | <input type="checkbox"/> |
| 9     |        |         |         | <input type="checkbox"/> |
| 10    |        |         |         | <input type="checkbox"/> |

Prefix  Replace  Account

## 24. Added contact group.

**Path:** Web Setting Page→Contacts→Local Phone Book

**Instruction:** Now the directory of T2x support contacts be viewed and managed in groups.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

10

Page: 1

**Contacts**

Name

Office Num

Mobile Num

Other Num

Account

Ring

Groups

**Group Information**

Groups

Ring

**Please select the contacts list file**

### Add Group

**Name:**  
 Ring                      Auto                      ◀▶

Back
abc
Delete
Save

25. Added LogOff to all web configuration pages.

**Path:** Web Setting Page

**Instruction:** Now you can see the LogOff button on all pages of web interface.



26. Supported import and export contact of CSV and XML format.

**Path:** Web Setting Page→Contacts→Local Phone Book

**Instruction:** You will able to import and export contacts of CSV and XML format file in the contacts manage page.

**Detail:** Please refer to User Manual of version 60 for detail. Click here for Yealink download website page.

Mobile Num   
 Other Num   
 Account Auto ▼  
 Ring Auto ▼  
 Groups Not In Group ▼

Add Edit Del Delete All

**Please select the contacts list file**

选择文件 未选择文件  
Import XML Export XML

选择文件 未选择文件  
Import CSV Export CSV ☒ Show title

Add Edit Search

27. Enabled the number of messages in voicemail display.

**Path:** Phone Setting Page→Menu→Messages→Voice Mail→View Voice Mail

**Instruction:** Now you can view the amount of the voice mail that includes new and old voice mail.

### View Voice Mail

**1.Account1:                      Unregistered**  
**2.Account2:                      Unregistered**  
**3.34:                                0 new 0 old Mail**  
**4.Account4:                      Unregistered**

Back
Connect

28. Supported CODE of BLF List configurable.

**Path:** Web Setting Page→Account→Advanced

**Instruction:** BLF list is a function which can monitor the group status, it is not one to one monitoring, but the information feedback from the server to decide which BLF list will monitor which account. Now support to edit the code of BLF List.



29. Supported Delay Time of DialNow configuration.

**Path:** Web Setting Page→Phone→ Features

**Instruction:** Now the delay time of Dial Now can be configured.



30. Added POOL item in Softkey.


**Instruction:** When you off-hook, you will see the Pool Softkey on LCD, you can enter the History/Local Directory/Remote Phonebook/LDAP/Broadsoft Directory through it.

31. Added limit of input characters in DSSKEY-DTMF.

**Instruction:** Now increase the input character limit of DSSKEY-DTMF, now can only enter the number & ‘\* # ABCD’.

32. Modified the arrangement of the Softkey.

**Instruction:** E.g. a coming call when a new call comes in, Softkey3 is empty; Softkey Layout deletes the call states of Conference to/Conference/RingBack/Conference Talk.



33. Added Black List in T20.

**Path:** Web Setting Page→Contacts→Blacklist

**Instruction:** Now T20 also supports Blacklist.



34. Supported Greek displayed

**Instruction:** Now T2x support Greek displayed.

35. Supported Blind Transfer could be disabled.

**Path:** Web Setting Page→Phone→Features


**Instruction:** Now user can disable the blind transfer function.



36. Added Hold function with RFC2543.

**Path:** Web Setting Page→Phone→Features

**Instruction:** There two standards of Hold, user can enable the hold standards accord RFC 2543, it needs server support.



37. Supported whether disposed the ring tone after Coloring Ring Back Tone is optional.

**Path:** Web Setting Page→Phone→Features

**Instruction:** This option is use for whether to play the ring back tone after a Coloring Ring Back Tone.



38. Enabled whether to terminate the 3-way conference when host hang up.

**Path:** Web Setting Page→Phone→Features

**Instruction:** In a 3-way conference, when the conference initiator hands up, the conference will not end up, this call will transfer to another two parties, so they can still on that call.

